



## Here's how to start the GyroTwister



### STEP 1

Hold the GyroTwister in your hand so that the covered upper section lies completely within your palm area. The opening is left free and points away from your hand.



### STEP 2

Insert one end of the starting cord included into the rotor hole of the GyroTwister. Continue wrapping the entire cord until tight and a short end remains for you to grasp.



### STEP 3

Hold on tight to the GyroTwister! Pull the cord out hard enough so that it doesn't touch the main body. Pull as fast as you can – as if you were starting a lawnmower. Make sure that you pull the cord out towards the front and not the sides, otherwise it could become caught in the inside parts.



### STEP 4

Hold the GyroTwister with the opening facing the bottom. Feel the movement and continue making a gradual turning movement back and forth (either clockwise or counter-clockwise around 2 rotations per second). Increase the speed slowly.